


(with internal camera inputs)

DS XPress Rear Panel



INSTALLING HARDWARE

1. Unpack the DS XPress unit and peripheral equipment.
2. Install the DS XPress unit in its permanent location.
3. Connect all peripheral equipment to the connectors as shown in this diagram.
4. Turn on the power supply switch on the DS XPress rear panel.
5. Turn on the power switch on the DS XPress front panel.
6. See the reverse side for information about configuring the DS XPress unit.

The user manual and installation/field service manual contain more information about the installation and configuration of your DS XPress system.

STOP! Do not install any unsupported software or hardware on your DS XPress system! This could automatically void the warranty.