

MANTRAP Application for In/Out readers on each door.

- 1) **MUST** use door contacts on each door.
- 2) **MUST** configure reader 1 and reader 2 to use shunt relays.

